



## HOW TO CLEAN YOUR ACOUSTIC TUBE EARPIECE

For best performance, your clear acoustic tube earpiece requires regular maintenance and cleaning. Over time the clear tube can become blocked with condensation, dirt, earwax, or body sweat. Cleaning the earpiece improves performance and prolongs the life of the clear tube and other parts.

1. Disconnect and remove tube from transducer clip.



2. Check for debris on the inside of tube, elbow and tube connector.



3. Soak the whole tube in warm water (not hot) for 10 minutes. Earbud or ear mold should be detached. Do not use soap or cleaning chemicals.



4. Using an air can, dry and blow out any additional debris and water from the tube.



6. Wipe the tube dry with a towel. If the tube is not clear of debris, repeat the cleaning process.

7. Reattach tube to your transducer earpiece.